


# Pre-Target/Pre-Vault



- 1) You need to check the Pre-Vault area C-Blocks in AP0, verify that the chains are in place and locked. Bring AP0 keys.
- 2) Enter the Pre-Target & Pre-Vault Enclosures from the upstream end of AP0.
- 3) If Pre-Vault is Interlocked, you will need to control access through it into Pre-Target.
- 4) A & B proceed to Pre-Target Interlock Box #1 at the top of the stairwell and reset it.
- 5) A & B sweep the enclosure to Interlock Box #2,
- 6) Reset Interlock Box #2 and control access into Pre-Vault.
- 7) Reset Interlock Box #1 of Pre-Vault.
- 8) A & B sweep the enclosure to the stairwell. Check the area between the stairwell and the target wall
- 9) A & B exit the stairwell to reset Interlock Box #2 and control access out.